

AERODROME
CHART - ICAO



ARP
N45°00.1'
E037°20.9'

ELEV
53.0m

START (Additionally serves
as TAXIING) 119.8

ANAPA, RUSSIA

VITYAZEVO



AERODROME LIGHTING	RWY	DIRECTION (TRUE)	THR	BEARING STRENGTH
Approach: RWY 04 HIALS RWY 22 LIL	04	042°17'	N44°59.6' E037°20.3'	PCN 25 /R/B/X/T
Runway: Edge-white, last 600m yellow HIRL	22	222°17'	N45°00.6' E037°21.6'	
Threshold: Green				

ELEVATIONS AND DIMENSIONS IN METRES
BEARINGS ARE MAGNETIC

CHANGE: ILS LOC